

Antique Lever Lock Handle:

NOTE: If locking is desired, install mortise first. (Mortise sold separately.)

Works on 1-7/8" – 2 1/4" thick door. Thinner door will require spindle to be trimmed. Thicker doors will require a longer spindle.

- 1 Determine desired handle height.
- 2 Drill a 1/2" hole 1 3/4" on center back from edge of door/gate.
- 3 Insert spindle in hole and position handles on either side of door. Fasten handle plates with screws provided.

Directions are for guidance only. Requirements may vary due to individual circumstances. We recommend drilling smaller pilot holes before screwing to reduce the chance of splitting wood, and when going completely through wood products, drill from both sides.