

Spring Loaded Gate Wheel:

1. With gate in closed position, ensure at least 6" clearance under bottom of latch side of gate.
2. Position wheel assembly in desired position (inside or outside of gate frame) and mark bolt positions.
3. Drill 3/8" holes for carriage bolts through the gate frame.
4. Fasten wheel assembly to gate frame with carriage bolts provided.

Directions are for guidance only. Requirements may vary due to individual circumstances. We recommend drilling smaller pilot holes before screwing to reduce the chance of splitting wood, and when going completely through wood products, drill from both sides.

