

**IMPORTANT:** Failure to properly install Designer DripEdge<sup>®</sup> may result in avoidable damage or serious injury. Always wear personal protective equipment when performing installation. Read through all instructions prior to installation. Please contact us at 800-328-5858 with any questions.

### Step #1:

Confirm the fit of the Designer DripEdge<sup>®</sup> with your pull-out waste can. The fit will vary depending on the size of the pull-out door and type of door you have.

### Step #2:

Thoroughly clean the top of the door where the Designer DripEdge<sup>®</sup> will be installed. Remove any external contents and dry the area completely.

### Step #3:

Using a rag and rubbing alcohol, wipe the installation area again to remove any remaining dust or residue. Wipe the area until it is dry.

### Step #4:

Peel the layer of plastic covering the pre-applied UHB tape on the Designer DripEdge<sup>®</sup> and attach the Designer DripEdge<sup>®</sup> to the pull-out door with the tape side on the top of the door.

*Be accurate in your placement. If the Designer DripEdge<sup>®</sup> is placed in an incorrect spot, remove promptly and replace in its proper position.*

### Step #5:

Hold the Designer DripEdge<sup>®</sup> tightly against the door and apply reasonable pressure for one minute.

*Failure to allow the tape to fully adhere to the door will compromise the integrity of the adhesive and may cause the Designer DripEdge<sup>®</sup> to loosen.*

### Step #6:

Clean the Designer DripEdge<sup>®</sup> with simple cleaning solutions and warm water routinely.

