



1. Install "B" Keeper 3/4" from edge of gate.
2. Install round bolt through "B" so handle touches "B"
3. Turn handle straight out from gate to reveal hole at "E" Ring Side.
4. Install "C" Keeper so that you can insert screw through both "C" and "E"
5. With handle touching "B" Keeper, slide "A" Keeper on to "D" so pad lock hole is showing
6. Mark position of "A" Keeper on post, slide round bolt out of "A", Screw "A" into place.
7. When bolt is closed, you can place a pad lock through "D"
8. There will be about 1-1/2" between "A" and "B".