



## SAN JUAN FLOATING COUNTER SUPPORT INSTALLATION INSTRUCTIONS

Every successful countertop installation begins with good planning and action. Do not wait until the last minute to order your countertop supports, fasteners or adhesives for installation. Make sure that all aspects of the support substructure are considered and discussed to ensure that your countertop installation will be smooth and that your countertop support products will be sufficient.

*Note this installation document should not be considered a specific recommendation for your particular application. Federal Brace cannot provide installation guidelines to meet the particulars of every application. This document should be considered a help sheet that provides considerations about the general characteristics of a particular type of support and installation.*

### Characteristics of the Alpine Elevated Counter Support

Our San Juan Support Brackets are designed to provide the support strength necessary to elevate and hold a counter or bar over a subcounter. The material thickness of the San Juan Elevated Countertop Bracket is 1/4".

### Preparations for the Alpine Elevated

The San Juan Support comes in both brushed stainless steel and raw steel materials. If you have ordered your San Juan Elevated Countertop Brackets unfinished (without paint) you will need to finish them before installation. Make sure you clean the bracket of any machine oil or rust preventative before painting. Once clean and dry at least 1 more coat. Before installing the brackets the paint should be allowed to dry completely.

### Considerations when Installing San Juan Countertop Support Brackets

Whenever installing the San Juan Countertop Brackets, make sure that you provide the thickest possible substructure (at least 3/4") on which to fasten the bracket. You will want the fasteners to have as much "biting" material as possible. This will provide with a secure fastening of the brackets. Also, the substructure must be tied into the floor. Remember, a weak substructure makes for a weak installation. In most instances blocking or additional furring on standard stud walls will be required to mount the base plate of the elevated countertop brackets.

With the substructure in place and sturdy, measure out your bracket pattern. We suggest that you space the Alta Vista style bracket no greater than 30" apart on a standard application. Once you have your bracket support pattern set up, you can attach your first bracket to the substructure. Make sure when you fasten the bracket that you check for level in all directions. The bracket should be vertical and level across the top flange as well as down the top flange. This will give the best possible support result to your countertop.

You should position the base plate of the Alta Vista Elevated Counter Support at such a height that it elevates the bar to the desired height over the sub counter. Once your first bracket is in

place, you can now add the additional brackets making sure that you check the additional brackets the same way you checked the first. Also, use a level to test each successive bracket installed to make sure that the whole installation is level. Placing the level from bracket top to top flange will help you reach this aspect of the installation.

Once all the brackets are in place you'll want to wipe them down to get rid of any handprints or other debris. Just before installation of your counter, apply adhesive or silicone to the top of the bracket to adhere it to the counter. Once the counter is in place, caulk around the edge of the brackets (if you choose). This will give greater adherence to the countertop and cover any gap

between the brackets and counter.

Final step is to enjoy your work and your new kitchen counter! We are very thankful that you chose to support your beautiful counters with Federal Brace bracket. We would be appreciative if you would send us images of your new kitchen and our brackets under your counters. We enjoy seeing Federal Brace supports at work.

Also, know that the highest compliment Federal Brace can be given is a reference from our customers to friends and family. If you have enjoyed your buying experience with Federal Brace please let someone know.

For any questions or comments please to contact us by email at [customerservice@federalbrace.com](mailto:customerservice@federalbrace.com) or by phone at (877) 353-8899. If you are a visual learner, check out our installation videos on our YouTube channel Don't forget to share your projects with your new Federal Brace brackets on Twitter and Instagram, just tag us @FederalBrace. Like us on Facebook, and check out our boards on Pinterest for more home improvement/decor and DIY project ideas.

