



## **GLASS BALL KNOB INSTALLATION**

- (1) Position knob on cabinet face and mark hole to be drilled.
- (2) Using a 1/8" bit, drill a 'pilot' hole through cabinet face where marked in step (1).
- (3) Using a 1/4" bit, drill 7/16" deep into the 'pilot' hole in order to recess post.
- (4) Attach knob to cabinet using screw provided.