

DOOR BOTTOMS

Applies to the following door bottoms:

SA1, SA2, SA3, SA4

Tools Required:



Installation Instructions:

1. Extend drop bar by pressing on actuator (plunger pin) with nylon tip (button), insert pin or nail in hole in metal case located near plunger pin, in order to hold drop bar in extended position.
NOTE: Be careful not to squeeze bar into case while nail is in place as damage to springs will result.
2. Measure length between door stops at floor level, and trim automatic door bottom 1/8" shorter than this length. Trim opposite end from nylon button.
3. Close door. Set automatic door bottom (between stops) and flush against floor (or threshold) with nylon button snugly against stop (hinge side of door).
4. Mark location of mounting screws and remove automatic door bottom, and open door. Remove pin (or nail) from case (allowing drop bar to retract) and mount on door with screws provided.
5. Nail metal strike plate (provided) to door stop at hinge side of door. Locate plate so lower end touches floor and so plate will be aligned with nylon plunger button when door closes.