


Installation Guide for Shower door Hinges



GLASS CUTTING



90°Glass-Glass; 180° Glass-Glass 90°Glass-Wall (without glass frame)



135° Glass-Glass

STANDARD DUTY WALL MOUNT HINGE

Maximum	3/8" (10mm) Glass		1/2" (12mm) Glass	
Capacities	Weight	Width	Weight	Width
Using 2 Hinges	80 lbs. (36kg)	28" (711mm)	80 lbs. (36kg)	28" (711mm)
Using 3 Hinges	120 lbs. (54kg)	32" (813mm)	120 lbs. (54kg)	32" (813mm)

^{*}NOTE: Do not exceed either maximum weight or width when choosing proper quantity of hinges

Installation Guide for Shower Door Hinges

SPECIFICATIONS

- Glass Sizes: 3/8"(10mm) to 1/2" (12mm) thick tempered safety glass
- Construction: Brass
- Closing Type: Self-centering when within 15° of closed position
- Cut-out required
- Includes: Gaskets, extra screws and template

Use of Gaskets

- For 3/8" (10mm) Glass: Use one thick gasket on each side
- For 1/2" (12mm) Glass: Use one thin gasket on each side

Recommendations

- For public safety, we recommend the use of only tempered safety glass.
- Do not use power tools when installing these hinges.

Maintenance Guidelines

- Our hinges are greased at the factory for quiet and trouble-free operation. If there is any squeaking that occurs after installation, put a drop of "3-in-1 Oil" (also known as "household oil") on the white nylon washer that the hinge body pivots on. This washer is the component that acts as a buffer, so the body of the hinge doesn't pivot directly on the brass center block. This solution doesn't require the disassembly of the hinge.
- Note: Do not use spray lubricant on these hinges. If the hinge has been disassembled, upon reassembly, use white lithium grease to lubricate the interior mechanism.
- Never use an abrasive cleaner on the hardware. Many of the components are coated with a clear lacquer that will be irreparably damaged if subjected to harsh, abrasive chemicals. Advise your customer that drying the hardware with a clean, soft towel on a daily basis is the best way to maintain the hardware. If mineral deposits build-up, mix a couple of drops of a mild liquid soap (such as Ivory or a similar product) into a cup of warm water. Using a soft, non-abrasive cloth, clean the hardware. Rinse thoroughly with clean, warm water and dry.